Workshop – Buckling Optimization of a Cantilever Beam

AN MSC NASTRAN SOL 200 TUTORIAL



Goal: Use Nastran SOL 200 Optimization

Before Optimization

- Weight: 15.12 kg
- x1 = T, thickness of wall
- = .01 m
- Load Case 1:
 - Buckling Factor 1: -242.19
 - Buckling Factor 2: 242.19



After Optimization

- Weight: 2.35 kg
- x1 = T, thickness of wall
- =.0016 m
- Load Case 1:
 - Buckling Factor 1: -1.0071
 - Buckling Factor 2: 1.0071





Details of the Structural Model





Buckling Factors for Load Case 1





Buckling Factors for Load Case 2

Mode 1

Buckling Factor: -1104.

Mode 2

Buckling Factor: 1104.







Optimization Problem Statement





Optimization Problem Statement, SUBCASE Assignment of Constraints

	Status ≑	Label ≑	Response Type [‡]	Analysis Type [⊕]	Description	Global Constraints \$	SUBCASE 1 🜩	SUBCASE 2 🜩	SUBCASE 3 💠	SUBCASE 4 💠	
		Search	Search	Search	Search						
						Analysis Types 🔶	Statics 🗸	Statics 🗸	Buckling 🗸	Buckling 🗸	
	0	rt	STRESS	STATICS	Stress, von Mises or maximum shear at Z1, of elements						
	0	r2	STRESS	STATICS	Stress, von Mises or maximum shear at Z2, of elements						
	0	R1	Equation								
•	0	R2	Equation								



More Information Available in the Appendix

The Appendix includes information regarding the following:

- Frequently Asked Question
 - What is the trust region?
- An example where the Trust Region can be used
- Trust Region Visualized
- Considerations for Optimization with Buckling Constraints





Contact me

- Nastran SOL 200 training
- Nastran SOL 200 questions
- Structural or mechanical optimization questions
- Access to the SOL 200 Web App

christian@ the-engineering-lab.com



Tutorial



Tutorial Overview

- 1. Start with a .bdf or .dat file
- 2. Use the SOL 200 Web App to:
 - Convert the .bdf file to SOL 200
 - Design Variables
 - Design Objective
 - Design Constraints
 - Perform optimization with Nastran SOL 200
- 3. Plot the Optimization Results
- 4. Update the original model with optimized parameters

Special Topics Covered

Optimization for Buckling - This example has multiple load cases and the goal is to avoid buckling for each load case. The SOL 200 Web App facilitates the configuration of multiple SUBCASEs and allows for optimization of multiple buckling scenarios.



SOL 200 Web App Capabilities

Compatibility

- Google Chrome, Mozilla Firefox or Microsoft Edge Installable on a company laptop, workstation or
- Windows and Red Hat Linux

server. All data remains within your company.

The Post-processor Web App and HDF5 Explorer are free to MSC Nastran users.

Benefits

entries.

- REAL TIME error detection. 200+
- error validations.
- REALT TIME creation of bulk data •
- Web browser accessible
- Free Post-processor web apps
 - +80 tutorials

Web Apps



Web Apps for MSC Nastran SOL 200 Pre/post for MSC Nastran SOL 200. Support for size, topology, topometry, topography, multi-model optimization.



Shape Optimization Web App Use a web application to configure and perform shape optimization.



Machine Learning Web App Bayesian Optimization for nonlinear response optimization (SOL 400)



Remote Execution Web App Run MSC Nastran jobs on remote Linux or Windows systems available on the local network



PBMSECT Web App Generate PBMSECT and PBRSECT entries graphically



Dynamic Loads Web App Generate RLOAD1, RLOAD2 and DLOAD entries graphically



Ply Shape Optimization Web App Optimize composite ply drop-off locations, and generate new PCOMPG entries



Stacking Sequence Web App Optimize the stacking sequence of composite laminate plies





HDF5 Explorer Web App Create graphs (XY plots) using data from the H5 file



Before Starting

 Ensure the Downloads directory is empty in order to prevent confusion with other files

- Throughout this workshop, you will be working with multiple file types and directories such as:
 - .bdf/.dat
 - nastran_working_directory
 - .f06, .log, .pch, .h5, etc.
- To minimize confusion with files and folders, it is encouraged to start with a clean directory.





The Engineering Lab

Go to the User's Guide

1. Click on the indicated link

• The necessary BDF files for this tutorial are available in the Tutorials section of the User's Guide.

Select a web app to begin Before After Optimization for SOL 200 Multi Model Optimization Machine Learning | Parameter HDF5 Explorer Viewer Study Tutorials and User's Guide (1)Full list of web apps

SOL 200 Web App



Obtain Starting Files

- 1. Find the indicated example
- 2. Click Link
- 3. The starting file has been downloaded

• When starting the procedure, all the necessary BDF files must be collected together.



Buckling Optimization of a Cantilever Beam

This example demonstrates the procedure to configure Nastran SOL 200 for buckling optimization. This example also covers how to optimize for multiple buckling scenarios.

Starting BDF Files: Link 2 Solution BDF Files: Link





Open the Correct Page

Click on the indicated link

- MSC Nastran can perform many optimization types. The SOL 200 Web App includes dedicated web apps for the following:
 - Optimization for SOL 200 (Size, Topology, Topometry, Topography, Local Optimization, Sensitivity Analysis and Global **Optimization**)
 - Multi Model Optimization
 - Machine Learning
- The web app also features the HDF5 Explorer, a web application to extract results from the H5 file type.



SOL 200 Web App

Select a web app to begin







Machine Learning | Parameter Study



Full list of web apps



HDF5 Explorer



Viewer



Upload BDF Files

- Click 1. Select Files and select buckling_cantilever_beam.bdf
- 2. Click Upload Files

The process starts by uploading all the necessary BDF files. The BDF files can be files of your own or files found in the Tutorials section of the User's Guide.

Step 1 - Upload .BDF Files





Create Design Variables

- 1. Click on the plus (+) icons to set the thickness as a design variable
- 2. The x1 variable has been created for the thickness property

 The necessary design variables, as detailed in the optimization problem statement, are created.

 Each step has hidden functionality for advanced users. The visibility is controlled by clicking + Options. SOL 200 Web App - Optimization Upload Variables Objective Constraints Subcases Exporter Results

Size Topology Topometry Topography

Step 1 - Select design properties

+ Options

Create DVXREL1	Property 🌲	Property \$ Property Description \$ Entry \$		Entry ID 💠	Current Value 🌲	
	Search	Search	Search	Search	Search	
•	E	Young's modulus	MAT1	1	6.89E+10	
•	NU	Poisson's ratio	MAT1	1	.33	
•	RHO	Mass density	MAT1	1	2700.	
1 🛨	Т	Thickness	PSHELL	1	1.0000-2	



Step 2 - Adjust design variables

+ Oţ	otions									X Delete Visible Rows
	Label ≑	Status \$	Property \$	Property Description ≑	Entry \$	Entry ID 💠	Initial Value	Lower Bound	Upper Bound	Allowed Discrete Values
	Search	Search	Search	Search	Search	Search	Search	Search	Search	Search
×	x1 (2) •	т	Thickness	PSHELL	1	1.0E-2	.001	Upper	Examples: -2.0, 1.0, THRU, 10.0,



Create Design Objective

- 1. Click Objective
- 2. Select the plus (+) icon for weight
- 3. The objective has been set to minimize the weight, no further modification is necessary
- The objective must always be a single and global response. A response such as weight and volume are single responses, are independent of load case, and can be used as an objective. Other responses require special care when set as an objective. For example, if the objective is stress, only the stress of a single component, e.g. von Mises, of a single element, of a single load case may be used.

Select a response

	Response Description ≑	Response Type 🗢
	Search	Search
2 🗗	Weight	WEIGHT
•	Volume	VOLUME
•	Eigenvalue	EIGN
+	Frequency	FREQ
•	Displacement	DISP





Step 2 - Adjust objective

+ Options

	Label	Status	Response Type	Maximize or Minimize	Property Type	ΑΤΤΑ	ATTB	ATTI
×	rO	0	WEIGHT	MIN 🗸	3	3 🗸	3 🗸	



Create Design Constraints

- 1. Click Constraints
- 2. Set the analysis type to SOL 101 Statics
- 3. In the search box, type 's'
- 4. Select the plus(+) icon 2 times for Stress to create 2 stress constraints
- 5. Configure the constraints as shown to the right
- Example: Configure the following for r1
 - Property Type: PSHELL
 - ATTA: 11 von Mises or [...]
 - ATTi: 1 (PID 3)
 - Upper Allowed Limit: 2.76E08
- Each step has a second row with empty input boxes. These boxes are search boxes and should not be confused with rows 3, 4, 5, etc. Use the search boxes to filter columns in tables with multiple rows.

SOL 200 Web App - Optimization	Upload	Variables	Objective	Constraints	Subcases	Exporter	Results
Constraints Equation Constraints				(1)			

Step 1 - Select constraints

Select an analysis type	
SOL 101 - Statics	~

Select a response

		Response Description ≑	Response Type ≑								
		s 3	Search								
	+	Displacement	DISP								
	÷	Strain	STRAIN								
	+	Element Strain Energy	ESE STRESS								
(4) 🖸 👘	Stress									
	+	Fatigue, pseudo-static fatigue analysis	FATIGUE								
	« 1	2 3 4 »	[5	10	20	30	40	50		

Step 2 - Adjust constraints

+ Options

	Label	Status ≑	Response Type [⊕]	Property Type	ATTA 🗢	ATTB ≑	ATTi ≑	Lower Allowed Limit	Upper Allowed Limit
	St	Sear	Search	Search	Search	Search	Search	Search	Search
×	r1	0	STRESS	PSHELL V	11 - von Mises or maximum shear : 🗸		1	Lower	2.76E08
×	r2	0	STRESS	PSHELL V	19 - von Mises or maximum shear		1	Lower	2.76E08



Create Design Constraints

1. Click Equation Constraints

- There are 2 methods of creating a constraint.
 - Method 1 Select a constraint from a given list of responses, e.g. Weight, Volume, etc.
 - Method 2 Create an equation.
- This page shows the use of Method 2 to create an Equation Constraint.

SOL 200 Web App - O	ptimization	Upload	Variables	Objective	Constraints	Subcases	Exporter	Results
Constraints Equation	n Constraints	1						
Step 1 - Select	constraints	S						

Select an analysis type



Select a response

	Response Description \Rightarrow	Response Type ≑
	Search	Search
+	Weight	WEIGHT
+	Volume	VOLUME
+	Displacement	DISP
+	Strain	STRAIN
÷	Element Strain Energy	ESE



 \sim

Step A - Optional - Create additional responses (1)

Create Design Constraints

Create a responses that corresponds to the buckling load factors for modes 1 and 2. These responses value will be labeled 'b1' and 'b2'

- 1. Scroll to Section A Optional Create additional responses
- Change the analysis type to: SOL 105 -Buckling
- Click the plus (+) icon for Buckling Eigenvalue/Factor 2 times to create 2 buckling factor responses
- 1. Configure the following for b1

• ATTA: 1

- A: 1 (Buckling Mode 1)
- 5. Configure the following for b2

• ATTA: 2 (Buckling Mode 2)

Select a resp	onse	
	Response Description 🗢	Response Type ≑
	Search	Search
+	Weight	WEIGHT
+	Volume	VOLUME
3 🛨	Buckling Eigenvalue/Factor	LAMA
+	Weight from Particular Material or Property ID	WMPID

Step B - Optional - Adjust responses

(2)

+ Options

Select an analysis type

SOL 105 - Buckling

	Label	Status ≑	Response Type [‡]	Property Type ≑	¢ ATTA	ATTB 🗢	ATTI ≑
	Se	Sear	Search	Search	Search	Search	Search
×	b1	0	LAMA		1 (4)		
×	b2	0	LAMA		2 5		



¥

Create Design Constraints

Create an equation constraint for each buckling mode. Since the buckling load factor can be negative, the absolute function (abs()) is used.

- 1. Scroll to section Step 3 Optional Create equation constraints
- 2. Click on Add Equation Constraint 2 times
- B. Configure the following for R1:
 - Equation: ABS(b1)
 - Lower Allowed Limit: 1.
- 4. Configure the following for R2:
 - Equation: ABS(b2)
 - Lower Allowed Limit: 1.

 A previous buckling analysis revealed negative buckling load factors (BLF). A negative buckling load indicates that buckling would occur if the load was reversed. To address negative BLFs, the absolute value of BLFs is constrained.

Step 1 - Create equation constraints 1



+ Options

	Label \$	Status ≑	Equation 🗢	Lower Allowed Limit		Upper Allowed Limit
	Search	Search	Search	Search		Search
×	R1	0	ABS(b1)	1.	*	3 Opper
×	R2	0	ABS(b2)	1.	>\$	Lipper



Assign Constraints to Load Cases (SUBCASES)

- 1. Click Subcases
- 2. Select each option in the select box (Hold down the Shift key on the keyboard and use the mouse to select multiple options)
- B. Click + Options
- 4. Mark the checkbox for Use Multidisciplinary (MD) Optimization
- 5. For SUBCASE 1 and 2, change the analysis type to Statics
- 6. Mark the checkboxes to assign the stress constraints to SUBCASE 1 and 2
- 7. For SUBCASE 3 and 4, change the analysis type to Buckling
- 8. Mark the checkboxes to assign the equation constraints (buckling constraints) to SUBCASE 3 and 4
- If the SUBCASE in the Case Control Section includes that STATSUB command, then to perform an optimization, then the SUBCASE should also be configured for BUCKLING as shown on this page.

Step 1 - Assign constraints to subcases

Display	Column	s									
Glob SUB SUB SUB SUB	al Constr CASE 1 CASE 2 CASE 3 CASE 4	aints		2							•
+ Op	tions (3)						Uncheck	visible boxes	Check visible	boxes
🗸 Use	Multidiso Status	Label \$	Optimization	Analysis Type	Description	Global Constraints 🗢	SUBCASE 1 ≑	SUBCA SE 2 💠	SUBCASE 3 🖨	SUBCASE 4 🗢	
		Search	Search	Search	Search		5)	C	7	
						Analysis Types →	Statics 🗸	Statics 🗸	Buckling 🗸	Buckling 🗸)
	0	r1	STRESS	STATICS	Stress, item code 11, of elements associated with PSHELL 1	6					
	0	r2	STRESS	STATICS	Stress, item code 19, of elements associated with PSHELL 1						
	0	R1	Equation								
	0	R2	Equation								U

(1)



- At the top right hand corner, click on Settings
- Ensure the checkboxes are marked and the respective values match as shown in the image to the right
- For each design cycle, the allowable change of variables is either kept constant or decreased, but never increased. An opportunity exists to adaptively vary the change of variables so that they can be increased or decreased automatically. For some optimization scenarios, the increase in allowable variable change can yield faster optimizations. In this example, the Trust Region is used. Refer to the Appendix for additional details.

Optimization Settings

Parameter ≑	Description 🗢	Configure ≑
Search	Search	Search
APRCOD	Approximation method to be used	2 - Mixed Method
CONV1	Relative criterion to detect convergence	Enter a positive real number
CONV2	Absolute criterion to detect convergence	Enter a positive real number
DELX	Fractional change allowed in each design variable during any optimization cycle	Enter a positive real number
DESMAX	Maximum number of design cycles to be performed	20
DISBEG	Design cycle number for discrete variable processing initiation	Enter a positive integer
GMAX	Maximum constraint violation allowed at the converged optimum	Enter a positive real number
P1	Print items, e.g. objective, design variables, at every n-th design cycle to the .f06 file	1
P2	Items to be printed to the .f06 file	✓ 15 - Print objective, design variab
ТСНЕСК	Topology Checkerboarding	-1 - Automatic selection (Default) 🗸
TDMIN	Minimum diameter of members in topology optimization	Enter a positive real number
TREGION	Trust Region	1 - Trust Region On



1

Match

Other

Configure Settings

- 1. Click Settings
- 2. Scroll to section Result Files
- 3. Select one of the following H5 output options
 - Create the H5 file with MDLPRM
 - Create the H5 file with HDF5OUT

- The H5 file is used by the Postprocessor web app to display MSC Nastran results.
- The H5 file is used by the HDF5
 Explorer to create graphs (XY Plots) of MSC Nastran results.

SOL 200 Web App - Optimi:		de Home
Result Files 2		< >
H5 Output Option Create the H5 file with HDF5OUT (su - Select an Option - Create the H5 file with MDLPRM (supp Create the H5 file with HDF5OUT (sup	Ipported in MSC Nastran 2022.2 or newer)	S S S DOPTPRM DESMA
	Result Files	\$ Parameter t HDFSOUT INPUT
3	H5 Output Option Create the H5 file with HDF5OUT (supported in MSC Nastran 2022.2 or newer) ✓ Select an Option Create the H5 file with MDLPRM (supported in MSC Nastran 2016.1 or newer) Create the H5 file with HDF5OUT (supported in MSC Nastran 2022.2 or newer)	



SOL 200 Web App - Optimization Upload Variables Objective Constraints Subcases Exporter Results

BDF Output - Design Model

< >

BDF Output - Model

Export New BDF Files

1. Click on Exporter

2. Click on Download BDF Files

 When the download button is clicked a new file named "nastran_working_directory" is downloaded. If the file already exists in your local folder, the folder name is appended with a number, e.g. "nastran_working_directory (1).zip"

assign userfile = 'optimization_results.csv', status = unknown,	≤
form = formatted, unit = 52	\$*
s	\$* Design Model
s	\$*
\$ \$ Created by MSC_Apex Version Harris Hawk on Jan 05, 2019 at 04:12:08	5**************************************
s	s
\$ Values exported in this file are expressed using the consistent SI unit	S Design Variables - Type 1
\$ system	\$
S Length m	s
\$ Mass ke	s
\$ Time s	s
\$ Force N	
S Angle rad	DVPREL1 1000001 PSHELL 1 T
S NOTE: Mastran requires the following angle values always he defined in	199991 1.0
\$ degrees, irrespective of the consistent unit system used for the rest of the	s
\$ entries	
\$ PCOMPS (THETAi , nly orientation angle)	DESVAR 100001 v1 1 0E-2 001
\$ TABLED1 (vi - phase angle data when referenced in TP field of RLOAD2)	S S
s	S
4 Linear Buckling Scenario Buckling Scenario Part 1 (3)	-
S Scenario description	s
	c c
CEND	-
C HU	5 Decign Variables - Type 2
c .	
Control Requests	e e e e e e e e e e e e e e e e e e e
c c	· ·
<pre>S Displacement</pre>	-
	▼ c
	5
Download RDE Files	e e
Download BDF Flies	a Derice Objective
	e Destain oujective
	e e
± Download BDF Files 2	
	DECET 2000000 10 WEIGHT 3 3
_	
	> Design Constraints
	3
	2
	DRESP1 8000001 r1 STRESS PSHELL 11 1





Perform the Optimization with Nastran SOL 200

- 1. A new .zip file has been downloaded
- 2. Right click on the file
- 3. Click Extract All
- 4. Click Extract on the following window
- Always extract the contents of the ZIP file to a new, empty folder.

	ross ► Downloads ►	•	◆ Search Down	loads	م					
ganize 🔻 🛛 🔭 🏹 Oj	pen 🔻 Share with 🔻	New folder	8=	•	0					
Favorites	Name	8D	Date modifi	ed T	уре					
Desktop	🔒 nastran_working	_directory.zip	0 /25 /2019 0	46 014 0	omoress					
Downloads			Open in new wind	ow						
OneDrive		\bigcirc	Futract All							
			Edit with Notepad	++						
Libraries			Open with							
Documents			Share with		-					
J Music			Restore previous v	ersions						
Videos			Send to							
Homegroup			Cut							
			сору							
Computer			Create shortcut							
Network			Rename							
	•	III								
			Properties							
nastran_wo	orking_directory.zip Date n	nodified: 2/25/2								
nastran_wo Compressed	orking_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes) 🚹 Extr	act Com	pressed (Zipped	l) Folders			
Compressed	r king_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		🔵 🚹 Extr	act Com	oressed (Zipped	l) Folders			
nastran_wo Compressed	r king_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select	act Com	pressed (Zipped	I) Folders Extract File:	s		
nastran_wo Compressed	r king_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select	act Comp : a Dest I be extra	pressed (Zipped ination and cted to this fold	I) Folders Extract File: der:	s		
nastran_wo Compressed	r king_directory.zip Date n i (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files wil	act Comp a Dest l be extra	oressed (Zipped ination and cted to this fold I-sunshine\Dow	I) Folders Extract File: der: vnloads\nastral	S n_working_di	rectory	 Browse
nastran_wo Compressed	r king_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files wil	act Comp a Dest I be extra rs\specia	oressed (Zipped ination and cted to this fold I-sunshine\Dow	I) Folders Extract File: der: vnloads\nastral	S n_working_di	rectory	Browse
nastran_wo Compressed	r king_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files will C:\Use	act Comp : a Dest I be extra Issecia v extracte	oressed (Zipped ination and cted to this fold I-sunshine\Dow d files when coo	I) Folders Extract File: Jer: wnloads\nastra mplete	S n_working_di	rectory	 Browse
nastran_wo Compressed	r king_directory.zip Date n i (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files will	act Comp a Dest l be extra rs\specia v extracte	oressed (Zipped ination and cted to this fold I-sunshine\Dow d files when col	I) Folders Extract File: Ier: vnloads\nastra mplete	S n_working_di	rectory	 Browse
nastran_wo Compressed	r king_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files wil C:\Use	act Comp a Dest l be extra rs\specia v extracte	ination and ination this fold -sunshine\Dow d files when cou	I) Folders Extract File: der: vnloads\nastrat	S n_working_di	rectory	 Browse
nastran_wo Compressed	rking_directory.zip Date n i (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files will	act Comp a Dest I be extra rs\specia v extracte	oressed (Zipped ination and cted to this fold I-sunshine\Dow d files when co	I) Folders Extract File: der: vnloads\nastra mplete	S n_working_di	rectory	 Browse
nastran_wo Compressed	r king_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files will	act Comp a Dest I be extra rs\specia v extracte	oressed (Zipped ination and cted to this fold -sunshine\Dow d files when co	I) Folders Extract File: Jer: vnloads\nastrat	S n_working_di	rectory	Browse
nastran_wo Compressed	rking_directory.zip Date n i (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files wil C:\Use	act Comp a Dest l be extra rs\specia v extracte	oressed (Zipped ination and cted to this fold I-sunshine\Dow d files when co	I) Folders Extract File: der: vnloads\nastral	S n_working_di	rectory	Browse
nastran_wo Compressed	rking_directory.zip Date n l (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files will	act Comp : a Dest I be extra rs\specia v extracte	ination and cted to this fold -sunshine\Dow d files when co	I) Folders Extract File: der: vnloads\nastral	S n_working_di	rectory	Browse
nastran_wo Compressed	rking_directory.zip Date n l (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files will	act Comp : a Dest I be extra Is specia v extracte	oressed (Zipped ination and cted to this fold -sunshine\Dow d files when co	I) Folders Extract File: Jer: vnloads\nastra mplete	S n_working_di	rectory	Browse
nastran_wo Compressed	rking_directory.zip Date n I (zipped) Folder	nodified: 2/25/2 Size: 114 bytes		Select Files will	act Comp a Dest l be extra rs\specia v extracte	oressed (Zipped ination and cted to this fold I-sunshine\Dow d files when co	I) Folders Extract File: der: vnloads\nastral	S n_working_di	rectory	Browse



Perform the Optimization with Nastran SOL 200

- 1. Inside of the new folder, double click on Start MSC Nastran
- 2. Click Open, Run or Allow Access on any subsequent windows
- 3. MSC Nastran will now start
- After a successful optimization, the results will be automatically displayed as long as the following files are present: BDF, F06 and LOG.
- One can run the Nastran job on a remote machine as follows:

 Copy the BDF files and the INCLUDE files to a remote machine.
 Run the MSC Nastran job on the remote machine.
 After completion, copy the BDF, F06, LOG, H5 files to the local machine.
 Click "Start MSC Nastran" to display the results.

Using Linux?

Follow these instructions:
1) Open Terminal
2) Navigate to the nastran_working_directory cd ./nastran_working_directory
3) Use this command to start the process ./Start_MSC_Nastran.sh

In some instances, execute permission must be granted to the directory. Use this command. This command assumes you are one folder level up.

sudo chmod -R u+x ./nastran_working_directory

OOO V W Oownl > nastran_working_directory > V	Search nastran_work	ing_dir 🔎	
Organize Include in library Share with New folder		0 Op	en Fil
Favorites	Date modified	Туре	
Nesktop	2/24/2018 1:57 PM	File folder)o yo
〕 Downloads 🛛 📝 design_model.bdf	2/24/2018 1:57 PM	BDF File	
🕮 Recent Places 📄 model.bdf	2/24/2018 1:57 PM	BDF File	1
ConeDrive	2/24/2018 1:57 PM	Shortcut	
☐ Libraries ☐ Documents		E	✓ Alwa
v∛ Homegroup			1







SOL 200 Web App - Status

Status

Republic Python MSC Nastran

Status

1. While MSC Nastran is running, a status page will show the current state of MSC Nastran

Name	Status of Job	Design Cycle	RUN TERMINATED DUE TO
model.bdf	Running	None	

 The status of the MSC Nastran job is reported on the Status page. Note that Windows 7 users will experience a delay in the status updates. All other users of Windows 10 and Red Hat Linux will see immediate status updates.



Review Optimization Results

After MSC Nastran is finished, the results will be automatically uploaded.

- Ensure the messages shown have green checkmarks. This is indication of success. Any red icons indicate challenges.
- 2. The final value of objective, normalized constraints (not shown) and design variables can be reviewed.
- The reader may realize some of the design cycles have the letter R appended, e.g. 1R, 2R, etc. Since the Trust Region was utilized, some design cycles do not meet certain reliability criteria and are rejected. In the event the Trust Region is used, but an optimum is not successfully achieved, it is recommended to try again with the Trust Region turned off. See the Appendix for more details.

Final Message in .f06



Objective





Questions? Email: christian@ the-engineering-lab.com



31

Results

Before Optimization

- Weight: 15.12 kg
- x1 = T, thickness of wall
- = .01 m
- Load Case 1:
 - Buckling Factor 1: -242.19
 - Buckling Factor 2: 242.19



After Optimization

- Weight: 2.35 kg
- x1 = T, thickness of wall
- =.0016 m
- Load Case 1:
 - Buckling Factor 1: -1.0071
 - Buckling Factor 2: 1.0071





- 1. The original input files, e.g. DAT, BDF, etc., contains the original values for the designed properties. These original values must be updated to use the new and optimized values.
- A new BDF file has been created in nastran_working_directory/workspace_b/ model_final.bdf.
- 3. The file model_final.bdf is a copy of the original input files but the original values for the designed properties have been updated to use the optimized values.
- If you were using multiple INCLUDE files, model_final.bdf is a combination of all INCLUDE files. The next few slides discuss an alternative method of using the PCH to BDF web app to update the values for the designed properties while preserving separate INCLUDE files.

Coord and a straight of the straight of th	an_working_directory 🕨 workspace_b 🔷 👻	🗖 🗖 🔀
Organize 👻 Inclue	de in library 🔻 Share with 💌 New folder	:= - 1 🔞
☆ Favorites	Name	Date modified Ty
🧮 Desktop	model_final.bdf	7/20/2022 2:32 PM No
Downloads		
Recent Places		
Libraries	▼ ∢ III	F.

Original Input Files

PSHELL	1	1	1.0000-	-21		1		
RBE 3	41022		39921	1 1 16	1.0	123	38635	38636
+	38637	38638	38639		38839	38941	38942	38943
+	38944	38945	38946	38947	39445	39446	39447	39448
+	39449	39450	39451	39683	39684	39685	39686	39687
+	39688	39689						
RBE3	41023		39922	123456	1.0	123	38635	38636

Updated BDF File (model_final.bdf)

PSHELL		1	.001554	:	1 1.0		1 .83333	3 0.0
RBE3	41022		39921	3 56	1.0	123	38635	38636
+	38637	38638	38639 3	88640	38839	38941	38942	38943
+	38944	38945	38946 3	8947	39445	39446	39447	39448
+	39449	39450	39451 3	9683	39684	39685	39686	39687
+	39688	39689						



- 1. Click Results
- 2. Click PCH to BDF



Select a Results App







Local Optimization (.f06)



Parameter Study (.f06)



Annual Long. Long.

Responses (.f06)

Road, Barbarbar, Browther Road, Sciences, Internation

1000-00 1000-00 5000000 1000-00 1000-00 500000 1000-00 1000-00 500000

Global Optimization Type 2 (.f06)

Sensitivities (.csv)



Topology Viewer (.des)

Miscellaneous Apps

HEAVE 1 MAR(DAVA, PD, C, L, DDWR) = 7, 80 * L**2 * 02044/ (\$200 * 12(11) * DAVA(**2 * 02044)	ME 4 11.00 IN 10 40	
BROKLENS F -PD * MUN / DOWN	90 1 110 10 11 10	
	26 - 11.0 - 11 - 11	
	NO - 11.00 14	
NEBUTE LTREES	ME - 1.00 10 11 10	
8(5),(3) * 7.80 * 78.00**2 * (3) DENEMA (5.3418 * (4)**2*3.00*) BUCKLING #	NO 0 1140 00 14 10	 • • • • • •
-0.35 * g / BRAR	DN 0 1100 00 11 00	



The original .bdf/.dat file has old information about the properties. The properties will be updated.

- 1. Select the model.pch file
- 2. Select the original file: buckling_cantilever_beam.bdf
- 3. A summary of updates that will be performed are shown
- 4. Click Download and a new updated BDF file is downloaded





1. Note the entries have been updated with the optimized properties

bucklir	buckling_cantilever_beam.bdf 🗵											😑 buckling	_cantilever_b	eam.bdf 🗵									
1956	S Mater	ial Reco	ord: Alu	minum 606	51-T6							1956	\$ Mate:	rial Rec	ord: Alu	minum 606	1-T6						
1957	MAT1	1	6.89E+3	10 —	.33	2700.				+		1957	MAT1	1	6.89E+	10	.33	2700.				+	
1958	+	2 76F+0	18									1958	+	2.76E+	08								
1959	\$ Eleme	nts and	Element	Properti	es for S	Section:	Constant	Thickn	288			1959	\$ Elem	ents and	Element	Properti	es for S	Section:	Constan	t_Thickne	33	- 1	
1960	PSHELL	1	1	1.0000-	-21		1					1960	PSHELL		1	1 .00155	4	1 1.0		1 .83333	3 0.0		
1961	RBE3	41022		39921	123456	1.0	123	38635	38636	+		1961					0					J	
1962	+	38637	38638	38639	38640	38839	38941	38942	38943	+		1962	RBES	41022		39921	123450	1.0	123	38635	30030	+	
1963	+	38944	38945	38946	38947	39445	39446	39447	39448	+	1	63	+	38637	38638	38639	38640	38839	38941	38942	38943	+	
1964	+	39449	39450	39451	39683	39684	39685	39686	39687	+		1 54	+	38944	38945	38946	38947	39445	39446	39447	39448	+	
1965	+	39688	39689									965	+	39449	39450	39451	39683	39684	39685	39686	39687	+	
1966	RBE3	41023		39922	123456	1.0	123	38635	38636	+		1966	+	39688	39689								
1967	+	38637	38638	38639	38640	38839	38941	38942	38943	+		1967	RBE 3	41023		39922	123456	1.0	123	38635	38636	+	
1968	+	38944	38945	38946	38947	39445	39446	39447	39448	+		1968	+	38637	38638	38639	38640	38839	38941	38942	38943	+	
1969	+	39449	39450	39451	39683	39684	39685	39686	39687	+		1969	+	38944	38945	38946	38947	39445	39446	39447	39448	+	
1970	+	39688	39689									1970	+	39449	39450	39451	39683	39684	39685	39686	39687	+	
1971	SPC	1	38641	123456								1971	+	39688	39689								
1972	SPC	1	38642	123456								1972	SPC	1	38641	123456							
1973	SPC	1	38643	123456								1973	SPC	1	38642	123456							
1974	SPC	1	38644	123456								1974	SPC	1	38643	123456							
1975	SPC	1	38645	123456								1975	SPC	1	30044	123456							
1976	SPC	1	38646	123456								1976	SPC	1	38645	123456							
1977	SPC	1	38842	123456								1070	SPC	1	30040	123456							
1978	SPC	1	38980	123456								1070	SPC	1	20042	123456							
1979	SPC	1	38981	123456								1000	SPC	1	20001	122456							
1980	SPC	1	38982	123456								1001	SPC	1	20201	123456							
1981	SPC	1	38983	123456								1981	SPC	1	38982	123456							

Original BDF/DAT File

Downloaded BDF/DAT File



Inspection of MSC Nastran Results with the Post-processor Web App



Normalized Constraints

- All constraints are normalized. For each design cycle, the maximum normalized constraint (NC) is reported in the Normalized Constraints plot.
- The Responses web app is used to inspect the corresponding response for each maximum normalized constraint value.
 - For the final design, the maximum
 NC is -.0028102 and corresponds to
 a buckling load factor of 1.0028.





Post-processor Web App

- The Post-processor web app is used to inspect the MSC Nastran results.
- The buckling load factor (BLF) is the eigenvalue.
- Consider subcase 3, mode 1.
 - For the initial design, the eigenvalue, or BLF, is -242.1896.
 - For the final design, the eigenvalue, or BLF, is -1.0028.
- If F is the load applied, then the buckling load F_b is equal to F * BLF. A negative buckling load factor indicates buckling occurs when the load is reversed, i.e. -F_b = F * -BLF.
- Refer to the Post-processor web app tutorials to learn more about MSC Nastran results.



Main Panel

-

the-engineering-lab.com	HEXAGON Technology Partner
-------------------------	-------------------------------

ectru	m		Eringo Plot			Shano Plot					
	0.04790		Fillige Flot			Shape Flot					
	0.04491	Dataset	NODAL/EIGENVECT	OR		NODAL/EIGENVECTOR					
	0.04191		X - X component			X					
	0.03892		Y - Y component			Y					
	0.03593		Z - Z component RX - RX component			Z RX RY RZ					
	0.03293	Field	RY - RY component								
	0.02994		TVZ - TVZ component			112					
	0.02694				-			-			
	0.02395				11			11			
	0.02096	Coordinate	CID=0 (Basic)		~	CID=0 (Basic)					
	0.01796	System	CID-0 (Dasic)			OID=0 (Dasic)		_			
	0.01497	Scale				1					
	0.01198	Factor									
	0.00898		DESIGN_CYCLE	0		DESIGN_CYCLE	0				
	0.00599		MODE	1		MODE	1				
	0.00299	. ·	SUBCASE	3		SUBCASE	3				
	0.00000	Domain		242 40060	2		242 40060				
	No Data		TIME_FREQ_EIGR 99196322		3	TIME_FREQ_EIGR	99196322	Ĵ			
			FREQUENCY	NaN		FREQUENCY	NaN	_			

Post-processor

Spec

< >

39

trum		Fringe Plot		Shape Plot		^
0.04656	Datasat		OP		OP	
0.04365	Dalasel	NODAL/LIGENVECT	OR	NODALIEIGENVECT	UK .	
0.04074		X - X component	-	Х	-	
0.03783		Z - Z component		Z		
0.03492		RX - RX component		RX RY		
0.03201	Field	RZ - RZ component		RZ		
0.02910						4
0.02619			-		-	1
0.02328	_		h		11	1
0.02037	Coordinate System	CID=0 (Basic)	~	CID=0 (Basic)	~	1
0.01746	0					1
0.01455	Factor			1		1
0.01164						1
0.00873		DESIGN_CYCLE	14	DESIGN_CYCLE	14	1
0.00582		MODE	1	MODE	1	
0.00291	Domain	SUBCASE	3	SUBCASE	3	
0.00000 No Data		TIME_FREQ_EIGR	-1.002810211 3046677	TIME_FREQ_EIGR	-1.002810211 3046677	
Data		FREQUENCY	NaN	FREQUENCY	NaN	



Post-processor Web App

The PSHELL thicknesses of the initial and final design are compared.

 Refer to the Post-processor web app tutorials to learn more about MSC Nastran results.





End of Tutorial



Appendix



Appendix Contents

- Frequently Asked Question
 - What is the trust region?
- An example where the Trust Region can be used
- Trust Region Visualized
- Considerations for Optimization with Buckling Constraints



Frequently Asked Questions

Question:

- The trust region was used in the tutorial.
- What is the trust region?

Optimization Settings

BDF	Output -	Design	Model
-----	----------	--------	-------

		Opti	mization	Control	Settings	5
DETERM DECHAY	10	D1	1	D 2	15	TREGTON 1
FIFKE DESEAA	40	-1	1	F2	15	TREGION I

Parameter \$	Description 🗢	Configure ≑
APRCOD	Approximation method to be used	2 - Mixed Method
CONV1	Relative criterion to detect convergence	Enter a positive real number
CONV2	Absolute criterion to detect convergence	Enter a positive real number
DELX	Fractional change allowed in each design variable during any optimization cycle	Enter a positive real number
DESMAX	Maximum number of design cycles to be performed	40
DISBEG	Design cycle number for discrete variable processing initiation	Enter a positive integer
GMAX	Maximum constraint violation allowed at the converged optimum	Enter a positive real number
P1	Print items, e.g. objective, design variables, at every n-th design cycle to the .f06 file	1
P2	Items to be printed to the .f06 file	15 - Print objective, design variab 🔹
TREGION	Trust Region	1 - Trust Region On 🔹



Frequently Asked Questions

Answer:

- When the Trust Region is used, the Move Limits after each design cycle are automatically increased or decreased.
- The Move Limits dictate the degree to which design variables can change during a design cycle.
- With each design cycle, a new design is found through approximate optimization and then validated by a subsequent finite element analysis. The Move Limits impact the reliability of approximate optimization.
- There are 2 benefits to using the Trust Region:
 - The Trust Region can enable faster optimizations for some, but not all optimization problems. This is achieved because the Trust Region can reduce costly finite element analysis and depend more on approximate optimization.
 - The Trust Region can help avoid scenarios where large design variable changes suddenly cause feasible designs to become infeasible designs. This is sometimes indicated by the the message: "BEST COMPROMISE TO INFEASIBLE DESIGN."



An example where the Trust Region can be used

Consider the example of this workshop.



After design cycle 1, note the following:

- The thickness design variable has gone from .01 to .001.
- The normalized constraint has gone from -1.0 to .7 and is a change from feasible to infeasible.
- The optimization terminated with the message: RUN TERMINATED DUE TO HARD CONVERGENCE TO A BEST COMPROMISE INFEASIBLE DESIGN

Inaccuracy in Approximate Model

- See the F06 output on the following slide.
- For Design 1, there is a large discrepancy between the structural results from the Approximate Model and an actual Finite Element Analysis. Normally, the discrepancies are small. This large difference is likely due to a large change in the design variable from .01 to .001.

Final Message in .f06

RUN TERMINATED DUE TO HARD CONVERGENCE TO A BEST COMPROMISE INFEASIBLE DESIGN AT CYCLE NUMBER = 2.

Normalized Constraints









An example where the Trust Region can be used, Continued F06 Output, Design Cycle Summaries Shown

🗎 model.f0									emodel f06 🔀					
Sum Cyc	imary of D e 1	esign	DESIGN	BUCKLI	1 S	SUBCASE =	B)	Summary of Design DESI Cycle 2	N CYCLE =	2 S	UBCASE =	3	•
3366 3367	INTERNAL ID	DRESP1 ID	RESPONSE LABEL	MODE NO.	LOWER BOUND	INPUT VALUE	OUTPUT VALUE	UPPE BO	3755 INTERNAL DRESP1 RESPONSE	MODE NO.	LOWER BOUND	INPUT VALUE	OUTPUT VALUE	UPPER BOUND
3369 3370	2 3	7000001 7000002	B1 B2	1 2	N/A N/A	-2.4219E+02 2.4219E+02	3.8170E+02 -3.8170E+02	N/A N/A	analysis, set A, followed by an optimization	1 2	N/A N/A	-2.6820E-01 - 2.6820E-01	2.6820E-01 2.6820E-01 2.6820E-01	N/A N/A
3371 3372 3373			DESIGN	I CYCLE =	1 :	UBCASE =	4		with approximate structural results, set B. On the next design cycle, a new finite element	N CYCLE =	2 S	UBCASE =	4	
3374 3375			-	BUCKLI	NG LOAD RESP	NSES			analysis is performed, set C, and confirms or	BUCKLI	NG LOAD RESPO	ISES		
3377 3378	INTERNAL ID	DRESP1 ID	RESPONSE LABEL	MODE NO.	LOWER BOUND	INPUT VALUE	OUTPUT VALUE	UP BO	results, set B.	MODE NO.	LOWER BOUND	INPUT VALUE	OUTPUT VALUE	UPPER BOUND
3379 - 3380 3381	4 5	7000001 7000002	B1 B2	1 2	N/A N/A	-1.1047E+03 1.1047E+03	1.5732E+03 -1.5732E+03	N/A N/A	 After design cycle 1, the approximate buckling load factors, set B, are substantially 	1 2	N/A N/A	-1.3747E+00 - 1.3747E+00	1.3747E+00 1.3747E+00	N/A N/A
3382 3383 3384				RETAINE	D DRESP2 RES	ONSES			different from the actual factors from a finite element analysis at the start of design cycle	RETAINE	D DRESP2 RESP	DNSES		
3385 - 3386 3387	INTERNAL ID	DRESP2 ID	RESPONSE LABEL	EQUATION ID	LOWER BOUND	INPUT VALUE	OUTPUT VALUE		2, set C. Some difference is allowed, but excessive differences are not allowed. The	EQUATION ID	LOWER BOUND	INPUT VALUE	OUTPUT VALUE	UPPER BOUND
3389 3390 3391 3392 3393	1 2 3 4	9000001 9000002 9000001 9000002	R1 R2 R1 R2	170001 170002 170001 170002	1.0000E+00 1.0000E+00 1.0000E+00 1.0000E+00	2.4219E+02 2.4219E+02 1.1047E+03 1.1047E+03 JANUARY 15. 201	3.8170E+02 3.8170E+02 1.5732E+03 1.5732E+03 9 MSC Nastran 12/	1/1	excessive differences could be due to large changes in the design variables during the optimization with approximation stage.	170001 170002 170001 170002	1.0000E+00 1.0000E+00 1.0000E+00 1.0000E+00	7 2.6820E-01 7 2.6820E-01 1.3747E+00 JANUARY 15.2019	2.6820E-01 2.6820E-01 1.3747E+00 1.3747E+00 MSC Nastran 12/	1.0000E+35 1.0000E+35 1.0000E+35 1.0000E+35 1.0000E+35
3394 3395								5	3783					

Structural Results of Design 0 based on Finite Element Analysis

Structural Results of Design 1 based on Approximate Model

Structural Results of Design 1 based on Finite Element Analysis



An example where the Trust Region can be used, Continued

After employing the Trust Region, an optimum is successfully obtained





Trust Region Visualized

The following slides are based on the optimization example shown below, and serve to visually depict the behavior of the Trust Region. This example is found in the MSC Nastran Design Sensitivity and Optimization User's Guide.



HEXAGON

49

Trust Region Visualized, Continued Local Optimization Results

When the Trust Region is used, the Local Optimization Results will show some design cycles marked with the "R" label.

The "R" labels indicate that the design cycle has been rejected. This usually occurs when the move limits are so large that the constraints are violated. The design cycle is rejected, a new design cycle with decreased move limits is performed and the design cycle is accepted if the constraints are within limits.





Trust Region Visualized, Continued Final Optimization Path

It should be noted that the final optimization path consists of the following design cycles:

- INITIAL
- 1
- 2
- 3
- 7
- 10
- 14

The following rejected design cycles are not part of the final optimization path and are not shown in the image to the right:

- ° 5R
- 6R
- 8R
- 9R
- 11R
- 12R
- 13R





Trust Region Visualized, Continued Final Optimization Path





Considerations for Optimization with Buckling Constraints



Up and Down Behavior During Optimization

When working with buckling load factors during an optimization, the results may appear to have an *up and down* behavior.

The following slides discuss more information to help understand this up and down behavior.



Maximum Design Constraint Value for each Design Cycle



Optimization Problem Statement

- Objective: minimize mass
- Constrain the absolute value of buckling load factor (1.0 < ABS(BLF))
- Vary the thickness of the walls
- Trust region off and not used



Response Surface of Buckling Load Factor

The response surface for the buckling load factor is sometimes partially rough or discontinuous.

The buckling load factor (BLF) is equivalent to this expression

- 1. BLF = MIN(r1, r2, r3, r4, r5, ..., ri)
 - MIN: Take the minimum value
 - r1: Eigenvalue of mode 1
 - r2: Eigenvalue of mode 2

 - ri: Eigenvalue of mode i



echnology Partne



Response Surface of Buckling Load Factor, Continued

The scatter plot shown to the right is the response surface for buckling load factor across the design space. Note the following:

- Partially Rough Surface The response surface for different areas of the design space has different characteristics, i.e. flat versus steep surfaces when going from sample 198 to sample 267. This difference is due to the BLF corresponding to the eigenvalues of different mode shapes.
- Discontinuous Surface Since the BLF can include negative values, the response surface is discontinuous, e.g. when going from sample 38 to sample 51. In other instances, say going from sample 38 to sample 20, the BLF values vary significantly.

As the optimizer transverses the design space, the optimizer will encounter the roughness and sometimes discontinuous regions of the response surface, hence, the optimization results appear to go up and down. The optimizer in MSC Nastran is a gradient based optimizer and requires the response surface to be continuous, which is why the optimizer might terminate when the optimizer attempts to move between discontinuous regions.





Another Example of a Rough Response Surface

Shown to the right is a different example of a response surface that is very rough. The response surface corresponds to the maximum value of sound pressures. In many cases, the use of MAX or MIN will cause rough or discontinuous in the response surface.

Be careful when using the MIN or MAX of multiple values during an optimization.





How to handle negative buckling factors during an optimization?

If you have negative BLFs there are 2 methods to handle negative BLFs.

- 1. For the optimization, consider using the absolute value, e.g. ABS(BLF). Refer to figures 1 and 2. This tutorial used the absolute value of the BLF.
- 2. Use the EIGRL or EIGR bulk data entries to restrict the range of BLFs. Refer to Example Entries.
 - 1. Entry EIGRL 10 is configured to consider any BLF between -5E6 and 5E6. Since fields 4 and 5 are blank, the default values of -5E6 and 5E6 are used.
 - 2. Entry EIGRL 11 is configured to consider only BLFs greater than .00001
 - 3. Entry EIGRL 11 is configured to consider BLFs between .00001 and 10000.



Example Entries

EIGRL	10			100
EIGRL	11	.00001		100
EIGRL	12	.00001	10000.	100

While this region of the design space is discontinuous, in some cases the optimizer never travels to these discontinuous regions and successfully converges elsewhere in the design space

