Workshop - Automated Structural Optimization of a Stiffened Plate

AN MSC NASTRAN SOL 200 TUTORIAL



Goal: Use Nastran SOL 200 Optimization

Optimize the weight of this structure while constraining stress and displacement

Before Optimization

Weight: 6.962

x1 = T, thickness of shell

$$\circ$$
 x2 = DIM2


$$\circ$$
 = .1 in.



Weight: 5.477

$$\circ$$
 x1 = T = .113 in.

$$\circ$$
 x2 = DIM2 = .0839 in.



Details of the Structural Model

Stiffened Plate

An effective way to keep the number of independent design variables to a minimum is by grouping designed elements by property type. A smaller set of independent design variables decreases the cost associated with the sensitivity analysis, allows the optimizer to perform more efficiently, and makes interpretation of the final results much easier.

A simple example is shown in Figure 8-20 and includes a plate with a hat stiffener. The design goal is to reduce the weight of the stiffened panel subject to stress and displacement constraints under two separate static load conditions. The thickness of the plate and the thickness of the hat stiffener are allowed to vary. The boundary condition creates a simply supported condition with the plate also restrained in the x direction along x=0.0. The first load case includes both uniaxial tension in the x-direction and a vertical pressure load in the z-direction. The second load case is a concentrated load applied in the +z direction at grid 10203, which is directly under the hat. The example illustrates how the beam library can be utilized to simplify the modeling and design tasks and how the beam offset relations can be adjusted as the structural properties change.





Figure 8-20 Plate with a HAT Stiffener

MSC Nastran Design Sensitivity and Optimization User's Guide Chapter 8 - Example Problems - Stiffened Plate




Optimization Problem Statement

Design Variables

x1: T1 of PSHELL 1 | .01 < x1 < 1. x2: DIM2 of PBARL 3 | .01 < x2 < 1.

W3A,B for each element = 1.5 + x1 / 2.0



Design Objective

r0: Minimize weight

Design Constraints

- r1: The max stress at end A of elements related to PBARL 3
- r2: The max stress at end B of elements related to PBARL 3

- r3: The von Mises stress of elements related to PSHELL 1
- r4: The von Mises stress of elements related to PSHELL 1

r5: The z component of displacement for node 10302


$$-.1 < r5 < .1$$

r6: The z component of displacement for node 10203



Optimization Problem Statement Design Variables


Design Variables



More Information Available in the Appendix

The Appendix includes information regarding the following:

- Frequently Asked Questions
 - How do I avoid the scenario where the offset causes the cross section to interfere with the plate?





Contact me

- Nastran SOL 200 training
- Nastran SOL 200 questions
- Structural or mechanical optimization questions
- Access to the SOL 200 Web App

christian@ the-engineering-lab.com



Tutorial




Tutorial Overview

- 1. Start with a .bdf or .dat file
- 2. Use the SOL 200 Web App to:
 - Convert the .bdf file to SOL 200
 - Design Variables
 - Design Objective
 - Design Constraints
 - Perform optimization with Nastran SOL 200
- 3. Plot the Optimization Results
- Update the original model with optimized parameters

Special Topics Covered

Creating Hundreds of Equation Driven Parameters - Certain parameters of the Finite Element Model may need to be adjusted as certain design variables change. For example, as the thickness of a plate changes, an attached stiffener's offset will depend on the thickness. This tutorials describes the process for automatically generating dozens or hundreds of these equation driven parameters.





SOL 200 Web App Capabilities


Benefits

- 200+ error validations (real time)
- Web browser accessible


- Automated creation of entries (real time)
- Automatic post-processing

76 tutorials


Capabilities




Web Apps for SOL 200 Pre/post for MSC Nastran SOL 200. Support for size, topology, topometry, topography and multi-model.




Machine Learning Web App
Bayesian Optimization for nonlinear
response optimization (SOL 400)




MSC Apex Post Processing Support View the newly optimized model after an optimization



Beams Viewer Web App
Post process 1D element forces,
including shear forces, moments,
torque and axial forces




Ply Shape Optimization Web App Spread plies optimally and generate new PCOMPG entries




Shape Optimization Web AppUse a web application to configure and perform shape optimization.




HDF5 Explorer Web App Create XY plots using data from the H5 file



Remote Execution Web App
Run MSC Nastran jobs on remote
Linux or Windows systems available
on the local network



Generate PBMSECT and PBRSECT entries graphically




Stacking Sequence Web AppOptimize the stacking sequence of composite laminate plies



Before Starting

 Ensure the Downloads directory is empty in order to prevent confusion with other files

- Throughout this workshop, you will be working with multiple file types and directories such as:
 - .bdf/.dat
 - nastran_working_directory
 - .f06, .log, .pch, .h5, etc.
- To minimize confusion with files and folders, it is encouraged to start with a clean directory.





Go to the User's Guide

1. Click on the indicated link

• The necessary BDF files for this tutorial are available in the Tutorials section of the User's Guide.

The Engineering Lab







Obtain Starting Files

- 1. Find the indicated example
- 2. Click Link
- 3. The starting file has been downloaded

 When starting the procedure, all the necessary BDF files must be collected together.








Open the Correct Page

1. Click on the indicated link

- MSC Nastran can perform many optimization types. The SOL 200 Web App includes dedicated web apps for the following:
 - Optimization for SOL 200 (Size, Topology, Topometry, Topography, Local Optimization, Sensitivity Analysis and Global Optimization)
 - Multi Model Optimization
 - Machine Learning
- The web app also features the HDF5 Explorer, a web application to extract results from the H5 file type.

The Engineering Lab






Step 1 - Upload .BDF Files

Upload BDF Files

- Click 1. Select Files and select dsoug4.dat
- 2. Click Upload Files

 The process starts by uploading all the necessary BDF files. The BDF files can be files of your own or files found in the Tutorials section of the User's Guide.





Create Design Variables

- 1. In the search box, type 't'
- 2. Click on the plus (+) icons to set the thickness as a design variable
- 3. In the search box, type 'dim'
- 4. Click on the plus (+) icons to set DIM2 as a design variable
- 5. Specify the lower bound as .01 for design variables x1, x2
- 6. Specify the upper bound as 1. for design variables x1, x2
- The necessary design variables, as detailed in the optimization problem statement, are created.
- The search boxes are used to filter the tables for the T and DIM2 properties.
- Each step has hidden functionality for advanced users. The visibility is controlled by clicking + Options.

Step 1 - Select design properties

+ Options

Create DVXREL1	Property \$	Property Description \$	Entry \$	Entry ID \$	Current Value
	t (1)	Search	Search	Search	Search
(2)	Т	Thickness	PSHELL	1	0.15
±	Т	Thickness	PSHELL	2	0.2

Step 1 - Select design properties

+ Орионъ

Create DVXREL1	Property \$	Property Description \$	Entry \$	Entry ID \$	Current Value \$
	dim 3	Search	Search	Search	Search
+	DIM1	HAT - Height of beam	PBARL	3	3.0
4	DIM2	HAT - Thickness of flange, web and li	PBARL	3	0.1
•	DIM3	HAT - Width of flange, top	PBARL	3	2.0
+	DIM4	HAT - Width of lip	PBARL	3	0.9

Step 2 - Adjust design variables

★ Delete Visible Rows

+ Options

	Label \$	Status \$	Property \$	Property Description \$	Entry \$	Entry ID \$	Initial Value	Lower Bound	Upper Bound	Allowed Discrete Values
	Search	Search	Search	Search	Search	Search	Search	5	6	Search
×	x1	0	Т	Thickness	PSHELL	1	0.15	.01	1.	Examples: -2.0, 1.0, THRU,
×	x2	•	DIM2	HAT - Thickness of flange, web and li	PBARL	3	0.1	.01	1.	Examples: -2.0, 1.0, THRU,



Create Design Variables

- 1. In the search box, type 'w3'
- 2. Select '10' in the pagination bar
- 3. Click +Options
- 4. Check the DVXREL2 option
- 5. Type in this equation:
 - 1.5 + x1 / 2.0
- 6. Click on Create
- In order to avoid interference between the beam cross section and thickness of the plate, a relationship is created between the beam offsets (W3A,B) and the variable representing the plate thickness (x1). A DVXREL2 entry defines this relationship.
- Design variables (DVXREL1) and DVXREL2 relationships can be individually created by clicking the blue plus (+) icons.
- If dozens or hundreds of variables or relationships must be created, the table can be used create these entries in one click by clicking the yellow icons named Create. In addition, the bounds, discrete values or equation can be configured rapidly.

Step 1 - Select design properties



Display Type	% Lower Bound	% Upper Bound	Lower Bound	Upper Bound	Allowed Discrete Values or Equation	Bulk Create
	(
☑ DVXREL1	Lower	Upper	Lower	Upper	Allowed discrete values, example: -2.0, 1.0, THRU, 10.0, BY, 1.0	✓ Create
□ DVXREL1 Unity	Lower	Upper	Lower	Upper	Allowed discrete values, example: -2.0, 1.0, THRU, 10.0, BY, 1.0	★ Create
4 VXREL2	Lower	Upper	Lower	Upper	1.5 + x1 / 2.0 (5)	∲ Create

Display Columns

☑ Create DVXREL1 ☐ Create Unity DVXREL1 ☑ Create DVXREL2 ☐ Entry Name

Settings for row filtering in tables

● Contains ○ Starts with ○ Ends with

Create DVXREL1	Create DVXREL2	Property \$	Property Description \$	Entry \$	Entry ID \$	Current Value \$
		w3 (1)	Search	Search	Search	Search
+	+	W3A	Component of offset vector wa at poi	CBAR	31	1.575
+	+	W3B	Component of offset vector wb at poi	CBAR	31	1.575
+	+	W3A	Component of offset vector wa at poi	CBAR	32	1.575
+	+	W3B	Component of offset vector wb at poi	CBAR	32	1.575
+	+	W3A	Component of offset vector wa at poi	CBAR	33	1.575
+	+	W3B	Component of offset vector wb at poi	CBAR	33	1.575
+	+	W3A	Component of offset vector wa at poi	CBAR	34	1.575
+	+	W3B	Component of offset vector wb at poi	CBAR	34	1.575





Create Design Variables

- 1. Click 10 on the pagination bar
- 2. 8 DVXREL2 entries have been created

 These entries define relationships between the beam offsets (W3A,B) and the plate thickness variable (x1). As the thickness variable changes, the offset is also updated and will avoid the situation where the beam cross section interferes with the plate thickness.

+ Options


	Label \$	Status \$	Property \$	Property Description \$	Entry \$	Entry ID \$	Initial Value	Lower Bound	Upper Bound	Equation
	Search	Search	Search	Search	Search	Search	Search	Search	Search	Search
×	C1	•	W3A	Component of offset vector wa a	CBAR	31	1.575	Minimum	Maximum	1.5 + x1 / 2.0
×	C2	•	W3B	Component of offset vector wb a	CBAR	31	1.575	Minimum	Maximum	1.5 + x1 / 2.0
×	C3	•	W3A	Component of offset vector wa a	CBAR	32	1.575	Minimum	Maximum	1.5 + x1 / 2.0
×	C4 (2)	•	W3B	Component of offset vector wb a	CBAR	32	1.575	Minimum	Maximum	1.5 + x1 / 2.0
×	C5	•	W3A	Component of offset vector wa a	CBAR	33	1.575	Minimum	Maximum	1.5 + x1 / 2.0
×	C6	•	W3B	Component of offset vector wb a	CBAR	33	1.575	Minimum	Maximum	1.5 + x1 / 2.0
×	C7	•	W3A	Component of offset vector wa a	CBAR	34	1.575	Minimum	Maximum	1.5 + x1 / 2.0
×	C8	0	W3B	Component of offset vector wb a	CBAR	34	1.575	Minimum	Maximum	1.5 + x1 / 2.0






Create Design Objective

- 1. Click Objective
- 2. Select the plus (+) icon for weight
- 3. The objective has been set to minimize the weight, no further modification is necessary
- The objective must always be a single and global response. A response such as weight and volume are single responses, are independent of load case, and can be used as an objective. Other responses require special care when set as an objective. For example, if the objective is stress, only the stress of a single component, e.g. von Mises, of a single element, of a single load case may be used.



Create Design Constraints

- **Click Constraints**
- 2. In the search box, type 's'
- Select the plus(+) icon 4 times for Stress to create 4 stress constraints
- 4. Select the plus(+) icon 2 times for Displacement to create 2 displacement constraints
- Select '10' in the pagination bar
- Configure the constraints as shown to the right
- Example: Configure the following for r1
 - Property Type: PBARL
 - ATTA: 7 End A maximum
 - ATTi: 3 (PID 3)
 - Lower Allowed Limit: -25000.
 - Upper Allowed Limit: 25000.
- The r1 label is configured as follows: A stress constraint is created for all elements associated with the entry PBARL 3, for component 7 (End A Maximum). PBARL 3 has 4 elements associated, so 4 stress quantities are constrained.
- The r3 label is configured as follows: A stress constraint is created for all elements associated with PSHELL 1 for component 9 (von Mises). PSHELL 1 has 16 elements associated, so 16 stress quantities are constrained.



Step 2 - Adjust constraints

+ Options

	Label	Status	Response Type	Property Type ⊕	ATTA ÷	ATTB \$	ATTi ≑	Lower Allowed Limit	Upper Allowed Limit
	Sŧ	Sear	Search	Search	Search	Search	Search	Search	Search
×	r1	0	STRESS	PBARL •	7 - End A maximum		3	-25000.	25000.
×	r2	0	STRESS	PBARL 🗸	14 - End B maximum		3	-25000.	25000.
×	r3	0	STRESS	PSHELL V	9 - von Mises or maximum shear at 🔻		1	Lower	25000.
×	r4	0	STRESS	PSHELL 🗸	17 - von Mises or maximum shear: 🕶	6	1	Lower	25000.
×	r5	0	DISP		3 - T3 (Rectangular z, Cylindrical z		10302	1	.1
×	r6	0	DISP		3 - T3 (Rectangular z, Cylindrical z		10203	03	.03



- 1. Click Subcases
- 2. Click Check visible boxes
- 3. Unmark the indicated checkboxes

(SUBCASES)

- The following constraints have been applied to SUBCASE 1: r1, r2, r3, r4, r5
- The following constraints have been applied to SUBCASE 2: r1, r2, r3, r4, r6
- When hundreds of SUBCASEs must be configured, the following options expedite the process:

Check visible boxes

Step 1 - Assign constraints to subcases

Display Columns

Global Constraints
SUBCASE 1
SUBCASE 2

□ Uncheck visible boxes

Check visible boxes



	Status	Label \$	Response Type	Description	Global Constraints \$	SUBCASE 1 \$	SUBCASE 2 \$
		Search	Search	Search			
=	0	r1	STRESS	Stress, item code 7, of elements associated with PBARL 3		☑	~
	0	r2	STRESS	Stress, item code 14, of elements associated with PBARL 3		☑	✓
	•	r3	STRESS	Stress, item code 9, of elements associated with PSHELL 1			~
	0	r4	STRESS	Stress, item code 17, of elements associated with PSHELL 1		~	~
	0	r5	DISP	T3 component(s) of displacement at grid 10302		3	
	0	r6	DISP	T3 component(s) of displacement at grid 10203			☑



Export New BDF

- Click on Exporter
- Click on Download BDF Files

When the download button is clicked a new file named "nastran working directory" is downloaded. If the file already exists in your local folder, the folder name is appended with a number, e.g. "nastran working directory (1).zip"

BDF Output - Model


```
assign userfile = 'optimization_results.csv', status = unknown,
form = formatted, unit = 52
$ Automated Structural Optimization of a Stiffened Plate with
$ MSC Nastran SOL 200/Design Optimization
$ field entries left justified for clarity
$ cbar entry line 1: vector v is z direction
$ cbar entry line 2: w3a and w3b that is fields 6 and 9
$ rename t-box as hatdim2
ID MSC DSOUG4 $ v2004 ehj 25-Jun-2003
$ Modified 31-May-2007 v2007 S_NATARAJAN
TIME 10
SOL 200
CEND
TITLE = STATIC ANALYSIS OF A STIFFENED PLATE
                                                            DSOUG4
ECHO = NONE
DISP = ALL
STRESS = ALL
SPC = 1
  DESOBJ(MIN) = 8000000
  $ DESGLB Slot
  $ DSAPRT(FORMATTED, EXPORT, END=SENS) = ALL
SUBCASE 1
  ANALYSIS = STATICS
  DESSUB = 40000001
```

Download BDF Files

■ Download BDF Files



BDF Output - Design Model




Developed by The Engineering Lab



Perform the Optimization with Nastran SOL 200

- 1. A new .zip file has been downloaded
- 2. Right click on the file
- 3. Click Extract All
- 4. Click Extract on the following window
- Always extract the contents of the ZIP file to a new, empty folder.





Perform the Optimization with Nastran SOL 200

- 1. Inside of the new folder, double click on Start MSC Nastran
- Click Open, Run or Allow Access on any subsequent windows
- 3. MSC Nastran will now start
- After a successful optimization, the results will be automatically displayed as long as the following files are present: BDF, F06 and LOG.
- One can run the Nastran job on a remote machine as follows:
 1) Copy the RDE files and the INCLUDE file
 - 1) Copy the BDF files and the INCLUDE files to a remote machine. 2) Run the MSC Nastran job on the remote machine. 3) After completion, copy the BDF, F06, LOG, H5 files to the local machine. 4) Click "Start MSC Nastran" to display the results.

Using Linux?


Follow these instructions:


- 1) Open Terminal
- 2) Navigate to the nastran_working_directory <u>cd</u> ./nastran_working_directory
- 3) Use this command to start the process ./Start_MSC_Nastran.sh

In some instances, execute permission must be granted to the directory. Use this command. This command assumes you are one folder level up.

sudo chmod -R u+x ./nastran working directory









Status

1. While MSC Nastran is running, a status page will show the current state of MSC Nastran

 The status of the MSC Nastran job is reported on the Status page. Note that Windows 7 users will experience a delay in the status updates. All other users of Windows 10 and Red Hat Linux will see immediate status updates.

SOL 200 Web App - Status

Python

MSC Nastran

Status

Name	Status of Job	Design Cycle	RUN TERMINATED DUE TO
model.bdf	Running	None	



Review Optimization Results

After MSC Nastran is finished, the results will be automatically uploaded.


- Ensure the messages shown have green checkmarks. This is indication of success. Any red icons indicate challenges.
- The final value of objective, normalized constraints (not shown) and design variables can be reviewed.
- After an optimization, the results will be automatically displayed as long as the following files are present: BDF, F06 and LOG.
- After the first design cycle, the weight is minimized from 7 to ~4.8, but after the second design cycle, the weight increases to ~5.4. This drop in weight, then slight increase is sometimes an indication a constraint was violated or near violation when minimizing weight, but then corrected by increasing weight. The normalized constraint at the initial design, after design cycle 1 and 2 are, -.1.64, .654 and .087, respectively, note the increase to .654, then drop to .087. The normalized constraint plot is not shown on this page but is visible to you when viewing the web app.

Final Message in .f06







Objective



(2)

Design Variables







Results

Before Optimization

Weight: 6.962


∘ x1 = T, thickness of shell

After Optimization

Weight: 5.477

$$\circ$$
 x1 = T = .113 in.


 \circ x2 = DIM2 = .0839 in.






Update the Original Model

- 1. The original input files, e.g. DAT, BDF, etc., contains the original values for the designed properties. These original values must be updated to use the new and optimized values.
- A new BDF file has been created in nastran_working_directory/workspace_b/ model_final.bdf.
- 3. The file model_final.bdf is a copy of the original input files but the original values for the designed properties have been updated to use the optimized values.
- If you were using multiple INCLUDE files, model_final.bdf is a combination of all INCLUDE files. The next few slides discuss an alternative method of using the PCH to BDF web app to update the values for the designed properties while preserving separate INCLUDE files.



Original Input Files



Updated BDF File (model_final.bdf)

			-(3)					
CBAR	31	3		10201	0.0	0.0	1.0	
	0	0	0.0	0.0	1.55637	0.0	0.0	1.5563
CBAR	32	3	10201	10202	0.0	0.0	1.0	
	0	0	0.0	0.0	1.55637	0.0	0.0	1.5563
CBAR	33	3	10202	10203	0.0	0.0	1.0	
	0	0	0.0	0.0	1.55637	0.0	0.0	1.5563
CBAR	34	3	10203	10204	0.0	0.0	1.0	
	0	0	0.0	0.0	1.55637	0.0	0.0	1.5563
Ş								
\$ Elements	and Elemer	it Pr	operties	for re	gion : Pla	ate		
PSHELL	1	1	.112735	1	1.0	0	.833333	0.0
		Ľ						
\$ Elements	and Elemer	it Pr	operties	for re	gion : Pla	ate 2		
PSHELL 2	1	0	.2 1					
\$111111122	2222233333	33334	44444445	5555555	666666667	7777777	8888888	9999999
\$ Elements	and Elemen	it Pr	operties	for re	gion : Ha	t Stiff	ener	
PBARL	3	1M	SCBMLO HA	AΤ				




Results

Home

Update the Original Model

- 1. Click Results
- 2. Click PCH to BDF

Select a Results App








Responses (.f06)



Global Optimization Type 2 (.f06)



Local Optimization (.f06)



Parameter Study (.f06)



Topology Viewer (.des)

Miscellaneous Apps








PCH to BDF



Update the Original Model

The original .bdf/.dat file has old information about the properties. The properties will be updated.

- 1. Select the model.pch file
- 2. Select the original file: dsoug4.dat
- 3. A summary of updates that will be performed are shown
- 4. Click Download and a new updated BDF file is downloaded



Step 3 - Download New BDF Files

On download, the PCH entries will replace older BDF entries.






Home

Update the Original Model

 Note the entries have been updated with the optimized properties



Original BDF/DAT File


Downloaded BDF/DAT File



The Engineering Lab

Beams Viewer

- 1. Navigate to the homepage
- 2. Click on the indicated link






Beams Viewer


1. Click the icon titled Beams Viewer to open the Beams Viewer

Beams






Machine Learning



Machine Learning




Prediction Analysis



Beams Viewer

- 1. Click Upload BDF
- 2. Click Select files
- 3. Navigate to the directory workspace_b
- 4. Select model final.bdf
- 5. Click Open
- 6. Click Upload files
- 7. The MSC Nastran model has been uploaded to the Beams Viewer






Upload the H5 File

If an H5 file was created, via MDLPRM, HDF5 or HDF5OUT, the H5 file may be uploaded to the Beams Viewer.


- 1. Click Upload H5
- 2. Click Select files
- 3. Select file nastran working directory/model.h5
- 4. Click Open
- 5. Click Upload files





Display Internal Element Stresses


- 1. Click Forces and Stresses
- 2. Mark the check boxes for axial and bending stresses
- 3. Stress arrows are now displayed on the 1D elements
- 4. Select the following:
 - 1. SUBCASE: 1
 - 2. ANALYSIS: 1
 - 3. DESIGN CYCLE: 5
- 5. Click the following buttons
 - 2D Elements
 - 2D Thicknesses





Adjust the Size of Labels

- 1. Use the vertical scroll bar
- 2. Locate the Display section
- 3. Click Size Controls
- 4. In the new panel, configure the following values:
 - Font Size: 0.0015
 - Arrow Length Stresses: 1.25
- 5. Click Element IDs
- 6. Rotate the model until element 34 is visible
- 7. Click Background Color
- 8. Click Label Color 2 times



End of Tutorial



Appendix



Appendix Contents


- Frequently Asked Questions
 - How do I avoid the scenario where the offset causes the cross section to interfere with the plate?



Frequently Asked Questions

Question:

• How do I avoid the scenario where the offset causes the cross section to interfere with the plate?



The offset (W3A and W3B) in this example causes the beam cross section to interfere with the plate



Frequently Asked Questions

Answer:

- In 'Step 4 Adjust DVXREL2', specify bounds that the offset property can take
- In this tutorial, this step was not necessary because the offset is in terms of x1 and x1 already has bounds applied

 Step 5 Adjust DVXREL2

★ Delete Visible Rows + Options Initial Value Status \$ Property # Property Description \$ Entry \$ Entry ID \$ Bound Equation Label \$ Bound Search Search Search Search Search Search Search Search Search 0 W3A Component of offset vector wa a... 1.5 + x1 / 2.0 W3B 31 1.575 1.5 + x1 / 2.0 Component of offset vector wb a... Maximum 1.5 + x1 / 2.0 Component of offset vector wa a.. W3B 32 1.5 + x1 / 2.0 Component of offset vector wb a... .1 Maximum 33 1.575 1.5 + x1 / 2.0 W3A Component of offset vector wa a... .1 Maximun 1.5 + x1 / 2.0 Component of offset vector wb a... CBAR 1.575 1.5 + x1 / 2.0 Component of offset vector wa a... CBAR 1.575 1.5 + x1 / 2.0 Component of offset vector wb a... CBAR

