# Workshop – Introduction to the PBMSECT Web App

A PBMSECT/PBRSECT TUTORIAL



# Goal: Modify an existing PBMSECT entry





# More Information Available in the Appendix

The Appendix includes information regarding the following:

- Procedure to Create PBMSECT/PBRSECT Entries
- Comment on Critical Points
- Supported PBMSECT/PBRSECT Keywords
- UFM 2012
- UFM 7201 Cause 1
- UFM 7201 Cause 2
- UFM 7733





#### Contact me

- Nastran SOL 200 training
- Nastran SOL 200 questions
- Structural or mechanical optimization questions
- Access to the SOL 200 Web App

christian@ the-engineering-lab.com



# Tutorial



# **Tutorial Overview**

- 1. Use the PBMSECT Web App to:
  - Edit an existing arbitrary beam cross section (ABCS) defined by a PBMSECT entry
  - Run MSC Nastran to confirm the ABCS is created properly

#### **Special Topics Covered**

**Arbitrary Beam Cross Section** - This tutorial introduces you to fundamental information regarding the use of the PBMSECT web app. After this tutorial, you will learn how to create arbitrary beam cross sections via the use of PBMSECT or PBRSECT entries.





# SOL 200 Web App Capabilities

#### Compatibility

- Google Chrome, Mozilla Firefox or Microsoft Edge Installable on a company laptop, workstation or
- Windows and Red Hat Linux

server. All data remains within your company.

The Post-processor Web App and HDF5 Explorer are free to MSC Nastran users.

#### Benefits

entries.

- REAL TIME error detection. 200+
- error validations.
- REALT TIME creation of bulk data
- Web browser accessible
- Free Post-processor web apps
  - +80 tutorials

#### Web Apps



Web Apps for MSC Nastran SOL 200 Pre/post for MSC Nastran SOL 200. Support for size, topology, topometry, topography, multi-model optimization.



Shape Optimization Web App Use a web application to configure and perform shape optimization.



Machine Learning Web App Bayesian Optimization for nonlinear response optimization (SOL 400)



**Remote Execution Web App** Run MSC Nastran jobs on remote Linux or Windows systems available on the local network



**PBMSECT Web App** Generate PBMSECT and PBRSECT entries graphically



**Dynamic Loads Web App** Generate RLOAD1, RLOAD2 and **DLOAD** entries graphically



Ply Shape Optimization Web App Optimize composite ply drop-off locations, and generate new **PCOMPG** entries



Stacking Sequence Web App Optimize the stacking sequence of composite laminate plies



browser on Windows and Linux



HDF5 Explorer Web App Create graphs (XY plots) using data from the H5 file



PBMSECT	1	0888	CP		
	OUTP=101	l,BRP(1)=	=102,T=1	.0	
POINT	1000001		0.0	-10.	
POINT	1000002		0.0	10.	
POINT	1000003		10.	10.	
POINT	1000004		10.	-10.	
POINT	1000005		-10.	10.	
POINT	1000006		-10.	-10.	
SET1	101	1000001	1000002	1000003	1000004
SET1	102	1000002	1000005	1000006	1000001

PBMSECT	1	0888	CP				
	OUTP=101	,BRP(1)=	=102,T=1.	.0			
POINT	1000001		0.0	10.			
POINT	1000002		-10.	10.			
POINT	1000003		-10.	-10.			
POINT	1000004		0.0	-10.			
POINT	1000005		10.	-10.			
POINT	1000006		10.	10.			
SET1	101	1000001	1000002	100003	100004	1000005	1000006

SET1 102 1000004 1000001



- When creating an arbitrary cross section (ABCS), there are many different configurations of the entries that will yield the same ABCS.
- For the ABCS shown on the right, 4 different configurations of the PBMSECT, POINT and SET1 entries are displayed. Each configuration yields the same ABCS with these properties.
  - Area: 9.9000E+01
  - I1: 5.9182E+03
  - I2: 5.3482E+03
  - I12: 0.0
  - J: 8.2246E+03

When you go through this tutorial, expect to get different IDs and sequences of entries. This is OK as long as your final arbitrary cross section matches what is shown in this tutorial.

PBMSECT	1	0888	CP		
	OUTP=101	L,BRP(1)=	=102,T=1	.0	
POINT	1000001		-10.	10.	
POINT	1000002		0.0	10.	
POINT	1000003		0.0	-10.	
POINT	1000004		-10.	-10.	
POINT	1000005		10.	-10.	
POINT	1000006		10.	10.	
SET1	101	1000001	1000002	1000003	1000004
SET1	102	1000003	1000005	1000006	1000002

PBMSECT	1	0888	CP				
	OUTP=101	,BRP(1)=	=102,T=1.	0, T(1) =	[1.0,PT=	(1000001,	,1000001)],T(2)=[
	1.0,PT=	(1000001,	100004)	]			
POINT	1000001		0.0	10.			
POINT	1000002		-10.	10.			
POINT	1000003		-10.	-10.			
POINT	1000004		0.0	-10.			
POINT	1000005		10.	-10.			
POINT	1000006		10.	10.			
SET1	101	1000001	1000002	1000003	1000004	1000005	1000006
SET1	102	1000001	1000004				



# Tutorial

#### PART A - CREATING AND CONNECTING POINTS



# PBMSECT Web App

- 1. Navigate to the homepage
- 2. Click on the indicated link

#### The Engineering Lab





#### PBMSECT Web App

1. Click the icon titled PBMSECT to open the PBMSECT web app

#### Beams





Beams Viewer

#### Machine Learning







**Prediction Analysis** 



#### Load Demo

- 1. Click Demo 1 to load an existing beam cross section
- 2. The cross section is displayed



Developed by The Engineering Lab



#### Points

- 1. Click Create Points
- 2. Configure the Grid Helper as follows
  - Width and Height: 30
  - Number of Divisions: 30
- 3. Click on the Grid Helper to create 5 points

Points				
Actions (1)	Adjustments			
Create Points     Create Points on Line	Point ID	Z	Y	
⊗ Remove Points	10000	-3.45	7.5	=
Settings - Grid Helper	10001	-3.35	6.5	
Width and Height	10002	-3.25	6.	
Number of 30 30	10003	-3.15	5.5	
Max allowable division: 2	10004	-2.75	5.	
$\smile$	10005	-2.5	4.5	
	10006	-1.65	3.9	
	10007	-1.55	3.	
	10008	-1.65	2.	
	10009	-1.85	1.	
	10010	-2.35	-1.	
	10011	-3.15	-3.	
	10012	-4.15	-5.6	
	10013	-1.25	-5.2	
	10014	.25	-5.	





#### Lines

- 1. Click Create Lines
- 2. Click on 2 points at a time to create 1 line
  - Repeat the process to create 6 lines as shown

Lines

Actions

Create Lines
 Remove Lines
 Select Lines of

Outer Perimeter

Deselect Lines of Outer Perimeter

Status: 📀

1

Default Th	nickness	
0.1		
Line Segr	nents	
Line ID	Туре	Thickness
1	OUTP	
2	OUTP	
3	OUTP	
4	OUTP	
5	OUTP	
6	OUTP	
7	OUTP	
8	OUTP	
9	OUTP	
10	OUTP	
11	OUTP	





### Outer Perimeter

- 1. Click Select Lines of Outer Perimeter
- Click on the 3 indicated lines to select the lines as part of the Outer Perimeter.
   Successful selection is indicated by a blue color.

#### IMPORTANT!

Defining the outer perimeter is the most critical step in defining the PBMSECT/PBRSECT entry. Constantly inspect the outer perimeter. Only one continuous outer perimeters is valid.

Line	S			
Actions		Adjustmen	ts	
- 0 × Re	erreate Lines	Default Th	iickness	
⊡ Se Oute	er Perimeter	Line Segn	nents	
ନ Des	select Lines of	Line ID	Туре	Thickness
Status:	⊘	1	OUTP	
		2	OUTP	
Color	Description	2	OUTP	
00101	Outer Perimeter	3	OUTP	
	(OUTP)	4	OUTP	
_	Possible lines for OUTP	5	OUTP	
	Critical Points	6	OUTP	
		7	OUTP	
		8	OUTP	
		9	OUTP	
		10	OUTP	
		11	OUTP	
		12	OUTP	
		13	OUTP	





### Cross Section Preview

- 1. Click Cross Section Preview
- 2. The cross section's thickness is now displayed. Each different colored line represents a different outer perimeter or branch.

Tools	
	O Center Model
	Fit Model
	Isometric View 1
	ZY View
	Background Color
	A Label Color
	A Labels
	Cross Section Actual A Size Controls
Demos	Cross Section Actual A Size Controls
Demos	Cross Section Actual A Size Controls
Demos	Cross Section Actual A Size Controls Clear Demo Demo 1
Demos	Cross Section Actual A Size Controls  Clear Demo Demo 1 Demo 2
Demos	Cross Section Actual A Size Controls
Demos	Cross Section Actual A Size Controls  Clear Demo Demo 1 Demo 2 Demo 3 Demo 4





#### Run MSC Nastran to Generate the Cross Section

The following requires MSC Nastran to be installed on the same machine as the SOL 200 Web App.

- The respective entries that define the arbitrary beam cross section are displayed
- 2. Click Run MSC Nastran
  - The web app will run MSC Nastran in the background and determine the cross section generated by MSC Nastran. This MSC Nastran run should take no more than 10 seconds. MSC Nastran must be installed on the machine as the SOL 200 Web App.
- 3. If the run is successful, the MSC Nastran generated cross section is displayed
- 4. Inspect the F06 file to inspect the result of the run
- 5. The test BDF file used for this test run may be downloaded by clicking Download Test BDF File

	Bulk	Da	ta	Er	ntr	ies	;														
5	R Dow	nload	Test	BDF	File	С	Ru	n MSC	: Na	stran	)(	2	)	) c	omp	olete					
	Corresp	ondir	ng B	ulk C	Data	Enti	ries														
	\$ 1	Ш	2	П	3	11	4	Ш	5	П	6	П	7	11	8	11	9	11	10	1	
	PBMSEC	T 10	(P=1)	088	38 7P=1	0P	RP=1	02.BR	P=1	03. B	RP=1	04.Т	=0.1		0	2					
	POINT	100	000	00,0		-3	.45	7.5		,.			0.1		(-	IJ					
	POINT	100	901			-3	. 35	6.5													
	POINT	100	902			-3	.25	6.													
	POTNT	100	003			-3	.15	5.5													

-2.75 5.

-2.5 4.5 -1.65 3.9

-1.55 3.

POINT

POINT

F06

POINT

POINT 10007

10004

10005

10006

-	¢	*	8	8	8	*	*	*	*	*	*	*	*	*	8	*	*	*	*	*
	\$	8																	*	*
	•	8						н	exa	agi	on	A	3						*	*
		*																	*	*
	•	*																	*	*
	•	*			,	4.3	5 (	c		N a	a :	s t		r a	a r	1			*	*
	•	*																	*	*
	•	*																	*	*
	¢	*																	*	*
	•	*			Ve	er	510	on	20	32:	2.1	1-(	L	372	236	58			*	*
	•	*																	*	*
		*																	*	*
		*																	*	*
		*							R	15		20:	22						*	*





#### Run MSC Nastran to Generate the Cross Section

- 1. If the MSC Nastran run was a success, an equivalent PBEAM entry is generated and listed in the F06 file. This PBEAM entry displays cross section information such as the cross sectional area and moments of inertia.
  - If a PBRSECT entry is created, a PBAR entry is generated.
  - If a PBMSECT is created with the CORE keyword, which is used for a composite section, a PBEAM3 entry is generated.
  - If a regular PBMSECT entry is created, a PBEAM entry is generated.

*** USER	INFORMATIO	N MESSA	GE 4379	(IFP9A)					
THE U	JSER SUPPLI	ED PBEA	ML/PBMSE	CT BULK DA	TA ENTRI	IES ARE	REPLACED B	Y THE FOI	LLOWING
CONVE	ERSION METH	OD FOR	PBARL/PB	EAML - FIN	UTE ELEM	MENT MET	HOD.		
PBEAM		10	888	6.4261E+0	0 1.549	99E+02	4.8931E+01	2.66038	2+01 8
	2.3293E+	01 1.5	356E+00	2.3293E+0	)1 1.43	56E+00	2.1343E+01	2.5356	2+00 2
	4.7070E-	01 4.6	340E-02	0.0000E+0	0.00	00E+00	0.0000E+00	0.0000	2+00 1
	0.000E+	0.0	000E+00	0.0000E+0	0.00	00E+00	1.2262E+01	-5.74138	2-01 1
CONFI	RMATION TE	ST OF P	BMSECT/P	BRSECT ENT	RY				JUNE
PBEAM		Ве	am Proper	ty					
<b>PBEAM</b> Defines th	e properties c	Be	am Proper	ty CBFAM en	try) This	element	may be used	to model t	apered
<b>PBEAM</b> Defines th	e properties o	<b>Be</b> of a beam	am Proper	ty CBEAM en	try). This	element	may be used	to model t	apered
<b>PBEAM</b> Defines th beams.	e properties c	Be of a beam	am Proper	ty CBEAM en	try). This	element	may be used	to model t	apered
<b>PBEAM</b> Defines th beams. <b>Format:</b>	e properties c	Be of a beam	am Proper	ty CBEAM en	try). This	element	may be used	to model t	apered
<b>PBEAM</b> Defines th beams. <b>Format:</b> 1	e properties c	Be of a beam 3	am Proper n element ( 4	ty CBEAM en	try). This	element	may be used	to model t	apered
PBEAM Defines th beams. Format: 1 PBEAM	e properties c	Be of a beam <u>3</u> MID	am Proper a element ( <u>4</u> A(A)	ty CBEAM en 5 I1(A)	try). This	element 7 I12(A)	may be used	to model t 9 NSM(A)	apered



#### Review the MSC Nastran Generated Cross Section

- The cross sections are displayed side by side to confirm the intended cross section has been properly created
- Note the edited portion of the cross section is now validated with MSC Nastran



Left: Actual cross section generated by MSC Nastran. Right: Predicted cross section.



#### Review the MSC Nastran Generated Cross Section

- 1. Click Labels
- 2. Click Fit Model
- 3. Lines measuring the point to point width and height are displayed
- Lines measuring the distance between the shear center and top, bottom, left and right cross section fibers are displayed



Developed by The Engineering Lab



#### Labels

- 1. Click ZY View
- 2. Click Cross Section Preview
- B. Click Cross Section Actual
- 4. Click Fit Model
- 5. The labels for the points, lines, width and height are displayed
  - Zoom in to see the labels for points and lines





#### Labels

- 1. Zoom in to see the labels for points and lines
  - The size of the labels are purposely small to avoid interference with nearby labels



#### Labels

- 1. Click Size Controls
- 2. Unmark the checkbox for Auto Manage Sizes
- 3. Increase or decrease the font size
- 4. The labels are resized





# Guidelines

PART B - GUIDELINES



# Guideline for Open Profile Sections

This guideline only applies if the arbitrary beam cross section is an open profile.

#### Guideline: The outer perimeter should connect all "critical points"

- A "critical point" is a point that has 3 or more connected lines
- There are exceptions to this guideline

The example on the right has 4 critical points: points 3, 4, 5, and 10. The outer perimeter (OUTP) are the blue lines. OUTP at best can cross 3 critical points. MSC Nastran cannot properly interpret this configuration.





# Guideline for Open Profile Sections

For this example, the solution is to remove the critical point that cannot be connected.

Lines 12 and 13 are a removed so that point 10 is no longer critical.

This configuration of OUTP is valid.





End of Tutorial



# Appendix



# Appendix Contents

- Procedure to Create PBMSECT/PBRSECT Entries
- Comment on Critical Points
- Supported PBMSECT/PBRSECT Keywords
- ° UFM 2012
- UFM 7201 Cause 1
- UFM 7201 Cause 2
- UFM 7733



#### Procedure to Create PBMSECT/PBRSECT Entries

- 1. Create points
- 2. Connect points and create Lines
- 3. Identify lines on the outer perimeter (<u>Critical Step</u>)
  - Guideline: If creating an open profile, the outer perimeter should connect all "critical points"
- 4. Fine tune the configuration
  - Select between PBMSECT and PBRSECT
  - Select general section, open profile or closed profile
  - Adjust the point's z and y positions
  - Adjust the line segment thicknesses
  - Specify custom IDs for POINT and SET1 entries
- 5. Run MSC Nastran to validate the PBMSECT/PBRSECT entry
  - This only works if MSC Nastran is installed on the same machine as the SOL 200 Web App







Composite Arbitrary Beam Cross Section Examples





### Comment on Critical Points

A critical point is a point with 3 or more connecting lines.

- 1. For open profile (OP) cross sections, the outer perimeter should always cross the critical points.
- 2. For closed profile (CP) cross sections, it is recommended that the outer perimeter cross the critical points.





Outer Perimeter

Possible lines for

Critical Points

(OUTP)

OUTP



#### Comment on Critical Points

- 1. For closed profile cross sections, it is <u>recommended</u> that the outer perimeter cross the critical points.
  - This recommendation is <u>NOT</u> absolute. As shown in the examples to the right, certain cross sections provide flexibility where the outer perimeter does not need to cross all the critical points.







#### Supported Bulk Data Entries and Keywords

The PBMSECT Web App supports the keywords listed in the table

#### Supported Bulk Data Entries

Entry	Import	Export
PBMSECT	YES	YES
PBRSECT	YES	YES
POINT	YES	YES
SET1	YES	YES
SET3	YES	NO

\*When uploading BDF files to the SOL 200 Web App, including the PBMSECT web app and Viewer, each entry listed in the table above must have a unique ID in all BDF files. The use of BEGIN MODULE allows for duplicate IDs for PBMSECT, POINT, SET1, etc. The following examples have duplicate IDs for POINT entries and are not supported by the SOL 200 Web App. All other DAT and BDF files are supported.

- /tpl/modules/mod\_vabcor2a.dat
- /tpl/modules/mod\_vabcore1.dat

#### Supported Keywords

Keyword	Supported?
OUTP	YES
OUTM**	NO
INP	YES
BRP	YES
т	YES
CORE or C	YES
LAYER or L	YES
NSM	YES

\*\*OUTM and BEGIN BULK ARBMODEL are not supported.

#### Supported Forms

- GS General Section
- OP Open Profile
- CP Closed Profile



#### UFM 2012

1. The IDs for the POINT entries may be customized as shown and is done to avoid conflicts with existing GRID IDs

AUTOMATICALLY GENERATED Q-SET SPOINT ID

#### Custom IDs

O Renumber Lines and Points

Entry	Custom ID	Status	IDs Used by this PBMSECT/PBRSECT	IDs Used by other entries
PBMSECT/ PBRSECT	78020	0	78020	
SET1	2000	0		
POINT	2001	Check separately to ensure POINT IDs do not conflict with GRID IDs		

(1)



### UFM 7201 Cause 1

1. This UFM sometimes occurs if line segments overlap





# UFM 7201 Cause 1, Another Example

1. If a free end of a line is very close to another line, the overlapping sections will trigger this error

```
*** USER FATAL MESSAGE 7201 (ARNFCK)
    PBRSECT/PBMSECT ENTRY ID=32, INTERSECTION OF SEGMENTS WITHIN A LOOP OR BETWEEN LOOPS FOUND.
    USER ACTION : IF FORM=CP OR OP, USE LESSER NUMBER OF POINTS TO DESCRIBE THE PROFILE. ESPECIALLY IN MERGING AREA OF TWO LINES.
        IF FORM=GS, CHECK FOR OVERLAPPING POINTS AND/OR POINTS WITH SAME COORDINATES.
        INTERSECTION
        X-COOR Y-COOR PROXIMITY POINT ID
        4.9407-324 0.0000E+00
        USER ACTION: MAKE SURE POINTS IN CLOSE PROXIMITY OF ABOVE COORDINATES ARE SEPARATED BY
        A DISTANCE LARGER THAN THE THICKNESS OF THE SEGMENT.
        PLEASE NOTE THAT LIST OF PROXIMITY POINTS IS NOT EXHAUSTIVE. REVIEW OF ALL POINTS INVOLVED IS RECOMMENDED.
        POST-SCRIPT OUTPUT FILE MAY BE UTILIZED AS A TOOL TO LOCATE THE PROBLEM SPOT.
*** USER FATAL MESSAGE 6624 (IFF9)
        SEE INFORMATION MESSAGES ABOVE
```

#### Not Correct: Point 8 is too close to line 15



Correct: Point 8 is moved to avoid being too close to line 15





#### UFM 7201 Cause 2

This UFM sometimes occurs if the POINT IDs are not numbered sequentially.

1. Click Renumber Lines and Points to automatically renumber the POINT IDs

Custom IDs						
Renumber Lines and Points						
Entry	Custom ID	Status	IDs Use PBMSE			
PBMSECT/	78020	0	78020			



Not Correct: The POINT IDs are not numbered in sequential order.



Correct: The POINT IDs are now numbered in sequential order.



#### UFM 7201

If this error persists, recreate the lines and ensure the next line created starts the end of the last line created.



